
"O" RING FITTING GUIDE

Fitting Instructions for Rubber Ring Joiners

STEP 1

Make sure pipe end is clean, smooth and free from defects, dirt and contamination.

Place rubber ring over machined end of pipe.

Make sure leg of rubber is at the front of pipe.



STEP 2

Stretch rubber to fit around pipe.



STEP 3

Ensure leg of rubber seal is over end of pipe all the way around.

If correctly fitted the rubber will be tapering upwards from the end of the pipe.



STEP 4

Use pipe lubricant (provided) to lubricate the first 50mm inside the bell of the pipe to be joined and the whole exposed surface of the rubber ring that is to be joined.

